



DIMENSIONS AND MOUNTING in metric millimeters



* Note that RS-485 signals are disconnected internally due to possible pickup of noise.

CONNECTION DESCRIPTION

Field selection of RS-232, RS-485/422 or 20mA TTY is done by using the corresponding leads on the 4m cable attached to the Readout. For RS-485/422 you need to open the compartment on the back using Torx TX-25 for the M4x10 screws, connect the Black and the Violet leads to terminals A+ and B- respectively.

STANDARD PROTOCOL DESCRIPTION

A lot of different protocol schemes may be programmed, and the following text only describes the Norsk Display factory default setup used on most products. A timeout function may auto blank the display after a preset number of seconds.

<STX>data<CR> where <STX>=ASCII 02d, <CR>=ASCII 13d, while data includes minus sign (-), decimal point (represented by '.' or ','), leading blanks or zeros.

ADDRESSING CONTROL

Including the leading string <SOH> AA will select display AA ('00' to '99'). '00' will broadcast to all connected displays. Addressing is relatively seldom used.

PROGRAMMING OPERATIONAL PARAMETERS

The ND5052 Display Controller has a host of predefined message formats (called protocols) that could be automatically detected or manually selected. A list of protocols is available on the Norsk Display website.

To set the parameters, please refer to the User's Guide for details. Depending on what parameters to change, the Test Button, IR Remote Control (option) or Terminal Hookup could be used. Terminal hookup will give you full control over operational parameters.

Use either a terminal program or the free Windows™ utility program to set the parameters. To enter programming mode, repeat '<Esc>+P' 16 times. The display will then respond with informational text, while the Readout will display „Prog“. Only simple configure commands will be accepted at 9600,8,N,1. After programming sequence, communication is set to the selected speed

Available commands are

S [enter]	Status - list all parameter settings
? [enter]	Help - list all available commands
V [enter]	list software number and version
C=1200 [enter]	set communication speed 1200-19200
P=N [enter]	set parity N,E,O
A=01 [enter]	set address 00-99. (00 means inactive)
PS=02 [enter]	set Protocol Start character (0=not used)
PE=13 [enter]	set Protocol End character
TO=05 [enter]	set TimeOut seconds (0 means not used)
TI=03 [enter]	set Ignore Characters after start
TL=07 [enter]	set Text Length = number of valid characters
RS=send [enter]	set Request String (^A for sending ASCII 01)
SP=02 [enter]	set Sign Byte Position (0 for not used)
SB=02 [enter]	set Sign Bit position in Sign Byte (0 to 8)
FT=kg [enter]	set max 3 character trailing text
BP=5 [enter]	set Control Byte Position (0=not used)
BM=07 [enter]	set Control Byte Bit Mask (0/255=not used)
BB=06 [enter]	set Control Byte Compare Byte
PP=0 [enter]	Particular Protocol (0=normal)
DL=6 [enter]	set Physical Display Length (6=normal)
DJ=R [enter]	set Justification R=Right / L=Left
DP=2 [enter]	set number of Decimals (place fixed dp)

EXAMPLE

To set the baudrate to 4800, issue the command:
Cmd[S=Status]>C=4800[Enter]

The PC/terminal will reply with an "OK" if accepted, else "* ERR". Use the „S“-command frequently. The Readout will not start using the parameters before leaving the programming mode and a restart is done.

Programming utilities with predefined setups are available online at <http://www.norskdisplay.com>.